

SG238 SUSPENSION TRAUMA RELIEF STRAPS**APPLICATION**

The SpanSet suspension trauma relief straps, when used in conjunction with a full body harness, are designed to aid in the prevention of suspension trauma after a fall from height has occurred.

INSTALATION

The suspension trauma straps should be installed at the junction of the shoulder strap and leg strap of the full body harness (refer fig 1.)

1.
Lay the exposed loop from the trauma strap pouch under the harness webbing



2.
'Choke' the pouch around the webbing and through the loop.



3.
Button pouch around harness Webbing, ensuring the press stud is below the 'choke'.



Fig 1

SG238 SUSPENSION TRAUMA RELIEF STRAPS**APPLICATION**

The SpanSet suspension trauma relief straps, when used in conjunction with a full body harness, are designed to aid in the prevention of suspension trauma after a fall from height has occurred.

INSTALATION

The suspension trauma straps should be installed at the junction of the shoulder strap and leg strap of the full body harness (refer fig 1.)

1.
Lay the exposed loop from the trauma strap pouch under the harness webbing



2.
'Choke' the pouch around the webbing and through the loop.



3.
Button pouch around harness Webbing ensuring the press stud is below the 'choke'.



Fig 1

SG238 SUSPENSION TRAUMA RELIEF STRAPS

4. Repeat the process for the other side of the harness, ensuring one pouch is marked “Hook” and the other pouch is marked “Loop”

USE

1/ Locate, unzip and deploy each case containing the suspension relief straps. (Fig 1)

2/ Raise the ends of the two straps to reach the hook and loops. Fit the hook through the loop that will give you the required length and lower the straps. (Fig 2)

3/ Step onto the strap to relieve the pressure on the legs and groin. (Fig 3) Repeat step two and three if the length is not suitable.



Fig 1



Fig 2



Fig 3

For further information refer to AS/ NZ 1891 or, contact SpanSet Australia Limited for guidance, selection, use and maintenance.

SpanSet® Safety First !!!!!

SPANSET AUSTRALIA LIMITED. ABN 75 003 298 459
13 Pullman Place (PO Box 164), Emu Plains, NSW 2750
Phone 02 4735 3955 Fax 02 4735 3630
www.spanset.com.au

SG238 SUSPENSION TRAUMA RELIEF STRAPS

4. Repeat the process for the other side of the harness, ensuring one pouch is marked “Hook” and the other pouch is marked “Loop”

USE

1/ Locate, unzip and deploy each case containing the suspension relief straps. (Fig 1)

2/ Raise the ends of the two straps to reach the hook and loops. Fit the hook through the loop that will give you the required length and lower the straps. (Fig 2)

3/ Step onto the strap to relieve the pressure on the legs and groin. (Fig 3) Repeat step two and three if the length is not suitable.



Fig 1



Fig 2



Fig 3

For further information refer to AS/ NZ 1891 or, contact SpanSet Australia Limited for guidance, selection, use and maintenance.

SpanSet® Safety First !!!!!

SPANSET AUSTRALIA LIMITED. ABN 75 003 298 459
13 Pullman Place (PO Box 164), Emu Plains, NSW 2750
Phone 02 4735 3955 Fax 02 4735 3630
www.spanset.com.au